





## Installation Instructions- Hollow Wall




Plaster board wall installation. Do not cover with insulation material.




1. Cutout size.




2. Prepare cutout in surface




3. Finish wall.




4. Make connection with driver.



5. Press springs toward the luminaire body and insert into the wall cut-out.



6. Remove protective film



7. Finished installation