




Lucent TubeLED Mini HO Installation Instructions



- Please read the following instructions carefully.
- Follow all national and local wiring and safety regulations.
- These products should only be installed by qualified personnel.
- The Low Voltage track systems require a PSU - DO NOT CONNECT DIRECTLY TO MAINS POWER!
- The mono point mounting can be installed with Lucent TubeLED Mini integral driver, which can be plugged to mains power. Or the spotlight can be applied with remote CC driver.
- To prevent damage to the system, only connect products manufactured by Lucent lighting and supplied as part of the TubeLED Mini mounting system
- Must keep the ambient temperature $\leq 25^{\circ}\text{C}$
- Do not exceed recommended loading weight and fixing distances.
- Retain these instructions for future reference.




Switch off mains power before installation.




Keep the ambient temperature $\leq 25^{\circ}\text{C}$ where the luminaires installed


TubeLED Mini HO Low Voltage Track application



1. After the installation of the low voltage track, connect with a 48V constant voltage power supply. Check the overall power required for the correct 48V power supply.




2. Insert the track adaptor into the track slot.




3. Clip the spotlight into the track adaptor and check whetehr it is fitted tightly


TubeLED Mini HO Mains Voltage Track application



1. After the installation of the mains voltage track, connect to the mains voltage. Before install the spotlights, do not turn on the mains power otherwise it would cause damage.




2. Twist to pull the conductive latch in and insert the track adaptor into the track slot.




3. Once it is fitted tightly, twist the conductive latch anti-clock way to catch the track and fix the entire spotlight. But do not turn on the mains power until all of the spotlights light in the track have been installed completely.


TubeLED Mini HO Surface Mono Point installation




1. Create a cable hole Ø12mm




2. Feed cables through



3. Feed cables through the bracket and secure the cable to the ceiling. Screw the bracket onto the ceiling tightly.




4. Make the electrical connection




5. Place the ceiling canopy over the bracket and then secure with a screw provided.


TubeLED Mini HO Recessed Mono Point Installation




1. Create a Ø70mm ceiling hole to allow the installation of the luminaire




2. Finish the ceiling surface




3. Paint and allow to dry fully



3. Push the springs inward and insert the Trim Kit




4. Clip and connect the security cable and make the electrical connection.




5. Clip and push spotlight top plate into the Trim Kit.


TubeLED Mini HO Trimless Recessed Mono Point Installation




1. Create a Ø70mm ceiling hole to allow the installation of the luminaire




2. Insert the Trimless Kit into the ceiling hole and then screw to fix the Trimless Mesh on the ceiling tightly.




3. Plaster to cover the mesh and allow to dry



4. Paint and allow to dry fully



5. Clip and connect the security cable and make the electrical connection.



6. Clip and push spotlight top plate into the Trim Kit.